

Fitting Instructions #2907IS

VW Polo 9N

Lower Engine Support Bracket Rear Mount Kit

Note: This kit is available in 2 versions:

- Kit # 2907-70K (Sports and Street applications).
 - Kit # 2907-80K (Competition applications).
-
- Remove the rear engine steady arm, 2 bolts on the base of the gearbox and the one through the sub frame and loosen the front bush through bolt;
 - Using an arbour press or similar remove the original bush. Lubricate all mating surfaces and insert the new polyurethane bush making sure the arrow and 'FRONT' are facing the front of the vehicle (refer to pictures). Lubricate the crush tube and push into bush;
 - Apply a light smear of grease to the raised sections in the sub frame where the bush locates, refit the arm and tighten all bolts to manufactures specifications.

